

Locating International® 6 cylinder Diesel Engine Serial Numbers

Please use this guide to help you locate engine serial numbers:

ENGINE MODEL	SERIAL NUMBER LOCATION
D 236 D 282 D 301 D 361, DT 361 D 407, DT 407	Stamped on the left-hand side of the engine on a pad located below the oil pump shaft support
D 310 D 358	Stamped on the right-hand side of the engine below the oil filter
DT 429	Stamped on the right-hand side of the engine on a pad located below the rear exhaust manifold
D 312 D 360	Stamped on the left-hand side of the engine on a pad to the front of the oil filter base
466 FAMILY	Stamped on the upper left-hand side of the engine crankcase below the intake manifold

Usually, only serial number sequence numbers are shown in the parts list. When necessary, engine model code, country of origin and use code may also be shown.

466 DF2 U 057402

